

Manual:

For craneable GS certified buckets and tubs for the transportation of water, sand, and mortar. These products meet the requirements for the guarantee for safety and healthy regarding the German product safety law § 20 bis 22 ProdSG.

Before using the tubs and buckets, these instruction must be read and saved!

Maximum load capacity:

- 12 Liter bucket 25 Kg. EMMT0120-3001 / EMMT0120-3501/EMMT0120-3002 / EMMT0120-2002
- 20 Liter bucket 45 Kg. EMMT0200-3001 / EMMT0200-3501
- 45 Liter tub 90 Kg. KUIT0450-3001 / KUIT0450-3501
- 90 Liter tub 250 Kg. KUIT0900-3001 / KUIT0900-3501

The maximum load capacity cannot be exceeded. Building materials cannot be discharged over the edge of the buckets and tubs.

The transport of metal parts, stones and similar is strictly forbidden! In case of strong wind and frost the buckets and tubs cannot be used.

First usage: before the first use is the bucket or tub in impeccable condition judged by an expert according to “§ 39 der Unfallverhütungsvorschriften Lastenaufnahmeeinrichtungen im Hebezeugbetrieb“.

The period of use of 5 years may not be exceeded. The period of use shall apply from the date printed in the bottom of the bucket or tub. After the expiration of this date the bucket or tub should be taken out of service.

Regular Inspection: the bucket or tub must be checked before any new lifting operation and during usage on damage. Also the handle need to be checked if it is still properly connected to the bucket or tub. Especially the inspection of the impeccable condition of the bucket or tub and the handle is necessary. In case of any deformations or notches in metal or plastic the bucket or tub must be taken out of service.

Maintenance: the bucket or tub must be emptied properly after usage and cleaned with water. The removal of dried debris remaining in the bucket or tub with sharp edged metal objects is not permitted.